

HLS 1200 DUO

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	



HERKULES LIFTING BY HEDSON

Herkules HLS 1200 DUO

The Herkules HLS 1200 DUO by Hedson is a user-friendly lift for workshops who need to lift the vehicles either on wheels or for a wheel free work position. A outstanding lift with double operation.

- 2,5 tons lifting capacity
- Lifting on the wheels or wheel free lift
- On-ground or flush mounted installations



HIGH CAPACITY

The Herkules HLS 1200 DUO is a user-friendly lift, with its loading capacity of 2,5 tons, for workshops who need to lift the vehicles either on wheels or for a wheel free work position



SPACE SAVINGS

The lift is easy to install and facilitate an individual planning of body shops by using the existing space optimally. It can be installed on-ground or flush mounted



ERGONOMIC

The lifting and lowering of the working height is done safely and smoothly optimizing the ergonomics and accessibility to all parts of the car during the job

HERKULES HLS 1200 DUO

Herkules HLS 1200 DUO -11 Part.no. HLS 1200-DUO-11

Herkules HLS 1200 DUO -14 Part.no. HLS 1200-DUO-14

Herkules HLS 1200 DUO -17 Part.no. HLS 1200-DUO-17

Weight 850 kg (1875 lbs)

Loading capacity 2,5 tons

Air supply 6 bar

Lifting height -11, -17 max. 930 mm

Lifting height -14 max. 825 mm

Working height -11, -17 ~ 1100 mm

Working height -14 ~ 1000 mm

Object height only -11, -17 110 mm

Pit depth -14 115 mm

Installation -11 On-ground

Installation -14 Flush mounted

Installation -17 Transmobile

ACCESSORIES

Pit frame (grids), zinc coated Part.no. 300-323

Pit frame (concrete), zinc coated Part.no. 300-326

Additional grids for the front end for HLS1200, 2 pieces, incl.
support angles + fasteners Part.no. 300-380

Drive over ramps, 2 pieces Part.no. 300-430

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	

hsc@nt-rt.ru || <https://hercules.nt-rt.ru/>